

uniball ZENTO



ZENTO3C Signature model(UBE3-ZHR)

取扱い説明書

※ご使用前に必ずお読みください。

ご注意

- 筆記及び描画以外の用途に使用しないでください。
- 先端がとがっているので注意してください。けがの恐れがあります。
- ペン先の樹脂玉を取り外してからご使用ください。
- ペン先を水平より上に向けての筆記は避けてください。インク漏れや筆記不良の原因になります。
- 使用後及び長時間使用しない場合や携帯時は必ずペン先を収納してください。衣服などを汚す原因になります。
- 落としたり、激しく振ったりするとインクが漏れる場合があります。
- 当商品は、磁石を使用しており、医療機器に影響を及ぼす恐れがあります。医療機器を使用されている場合は、ご使用前に医師または医療機器メーカーへご相談ください。


使用方法

〈ペン先の出し方〉

中軸の繰り出しマーク(■)を後軸の使いたい色に回し合わせてください。


〈ペン先の戻し方〉

中軸の繰り出しマーク(■)を色表示のないところに合わせてください。この時しっかりとペン先が収納されている事を確認してください。




〈ボールペン替芯の交換方法〉

- ①使用済みの芯を繰り出し、中軸を持った状態で先軸を矢印Aの方向に回して外してください。
 - ②使用済みの芯を引き抜いてください。
 - ③新しい芯を外した元の位置にしっかり止まるまで差し込んでください。
 - ④外した先軸を矢印Bの方向に回転させてしっかりしめます。
- ※替芯はUBR-ZML-38/05とご指定ください。



〈すべてのリフィルを同時に交換する場合〉

- ①黒の替芯を繰り出しマークに合わせて差し込んでください。
 - ②赤の替芯を左下に差し込んでください。
 - ③青の替芯を右下に差し込んでください。
- 繰り出しマークを色表示に合わせた際に色表示と同じ色の替芯が繰り出されるかを確認してください。



ボールペン替芯

ボール径	0.38mm	0.5mm
品 名	UBR-ZML-38	UBR-ZML-05
インク色	黒/赤/青	

※替芯のボール径、インク色はお好みでお選びいただけます。
※ご使用中の替芯をほかの商品に使用しないようご注意ください。
替芯の後端が変形し正しく装着できない場合がございます。

三菱鉛筆株式会社

〒140-8537 東京都品川区東大井5-23-37
お客様相談室 ☎0120-321433 MADE IN JAPAN

MADE IN JAPAN

uniball ZENTO



ZENTO3C Signature model(UBE3-ZHR)

Instructions

※Be sure to read these instructions
before using the product.

Caution

- Do not use the pen for purposes other than writing or drawing.
- Handle with care, as the tip is sharp.
- Remove the pen tip protector before use.
- Avoid writing with the pen upside down as this may cause ink leakage.
- Always replace the pen cap after use especially when not in-use for a long time or when carrying it.
- Dropping or vigorously shaking the pen may cause ink leakage.
- This product contains magnets, which may interfere with medical devices.
If you use medical devices, please consult your doctor or the device manufacturer before using this product.


Usage

<How to advance the pen tip>

Rotate the rear barrel while holding the mid-barrel. Align the clip with the selection mark. Ball point pen : Align the selection mark (■) of the color you want to use.

<How to retract the pen tip>


While holding the mid-barrel, rotate the rear barrel and align the clip with a part that has no selection marks. At this time, ensure that the pen tip is in the body.



<How to replace refills>

- ① Extend the used refill and, while holding the mid-barrel, twist the front barrel in the direction of arrow A to remove it.
- ② Pull and remove the used refill.
- ③ Insert the new refill until it settles into place.
- ④ Twist the removed front barrel in the direction of arrow B to securely tighten it.


※Use UBR-ZML-38 or UBR-ZML-05 refills.



<When replacing all refills at the same time>

- ① Insert the **black** refill aligned with the **selection mark**.
- ② Insert the **red** refill into the **lower left** slot.
- ③ Insert the **blue** refill into the lower right slot.

After inserting, please verify that the refill color matches the color indicator when the **selection mark** is aligned with it.



Insert each refill according to the positions shown in the diagram

Refills

Ball size	0.38mm	0.5mm
Mode	UBR-ZML-38	UBR-ZML-05
Ink color	Black/Red/Blue	

※Select from 3 ink colors and 2 tip sizes (0.38mm / 0.5mm) for your preferred refill.

※Please refrain from using used refills in other products.

MITSUBISHI PENCIL COMPANY, LIMITED
www.uniball.com

MADE IN JAPAN